



Unit 2/18 Gantry Place, Braemar NSW 2575

Tel: (02) 4872 3903 or 1800 20 70 92 Fax: (02) 4872 1815

www.automotiverestrains.com.au



## Seat Mounted Child Restraint for Toyota Commuter H32 Years 2019 and Later

### PART No. AH32 Anchorage Fitting Instructions

**Fitting Instructions** for Child Restraint Anchor Points into the Double & Single  
**Fixed Base Seat with GRAB HANDLES ONLY**

**Proudly Designed & Made in Australia by A.R.F.A**

#### TOOLS REQUIRED

- Small Flat Screwdriver
- Phillips Head Screwdriver (No.2)
- 4mm Allen Key

#### CONSUMABLES

- LOCTITE 243 thread locker

#### FITTING

1. Using small screwdriver, open flaps on the sides of the grab handles on the back of the seats.
2. Using the Phillips Head screwdriver, remove the grab handles and **discard** the 6mm screws that were holding the grab handles.
3. Place fibre washer provided onto M6 x 35mm (12.9 GRADE) Socket Head Cap Screws and using the Allen Key push cap screw through grab handle and also through the AH32 CRA bracket.  
**\*USE FIBRE WASHERS UNDER CAP HEAD**
4. Before fitting handle and bracket back in place use 1 drop of EG: LOCTITE 243 LOW STRENGTH THREAD LOCKER onto the M6 X 35MM SCREW THREAD and tighten firmly by hand so as not to force bolt through grab handle.

*Note: The anchor plate fits with the curved side downwards.  
Must be fitted by Authorised Fitter.*

TEST REPORT RN 190623  
COMPLIES TO ADR 34/03  
REG. DESIGN

*Allows for up to 8 anchorages per vehicle.  
Top child restraint tether fits under hand grab.*

